




This is the microphone for users of the Mediasite system.




To access the power button, you will need to squeeze the two door release latches located on the sides.



Press the power button once



Once you have pressed the power button, you can close the door and begin using the microphone.



When your Mediasite session is over, reverse the process and return the microphone to the charging dock. When it is resting properly in the charging dock, you will see the red charging indicator light come on.